



HSL/SL lock status display

Article No.: RB 800

Belt position indicators consist of a fastening screw and a stainless steel sleeve. The unit is bolted to the removal catch of HSL and SL locks. Depending on the door thickness and lock seat, indicator lengths from 7 mm to 52 mm are available.



Properties

- Reliably visualises the locking position
- Torx screw S25
- Flexible installation length available in 5 mm increments
- 7 mm to 52 mm

Functional description

External visual indicators visualise the bolt position on the door leaf. By using these display units, it is possible to check the locking position of the locks "in passing" without touching the door or lock.